







DISTRIBUTED BY: RAFT MODELS, INC.


1502 W. 228TH ST., TORRANCE, CALIF. 90501


## PART DRAWINGS AND PART NUMBERS (Before Assembling Your Kit)

Read these instructions carefully before assembling your model and check the exact fit of the parts before cementing. Clean off excess plastic, if any, with a sharp knife or a file. Since many tiny parts are included, check them with the assembly drawing before assembling. Do not tear off parts from the stem, but cut them off carefully with knife or clippers. Do not cut off all of the parts at the beginning, but cut each part to be assembled, one by one, to assure each part being properly identified. Do not use too much cement because surplus adhesive can spoil the finish.









## Assembly of fuselage, cockpit, pilot and air intake.

Fuselage (left) Fuselage (right) Cockpit (rear)

Separator (left)

Pilot (rear)


1

(5)

Separator (right)

Air intake (left) Air intake (right)

Cockpit (fore) Pilot (front)



Assembly of wing, tail, canopy and tanks to fuselage.


ain wing abilizer ertical plane and rudder

Nose pitot tube Wing tip tank (A)

34)

Wing tip tank (B) (35)Canopy

11



## 3 Assembly of landing gear and armament.

Main wheel cover (right) 12 Jet exhaust nozzle

Main wheel cover (left) (14) Nose wheel Main wheel cover (right) Nose wheel cover (sm) 15

Under fuselage tank shackle Nose wheel cover (Ige) 16 Under fuselage tank (upper) Main wheel strut (left) (17) Under fuselage tank (lower) (18)

Main wheel strut (rt) Under-wing tank shackle Main wheel Under-wing tank (upper) Main wheel cover (left) 20


Under-wing tank (lower)

Bomb shackle Bomb (lower) 22


(36)


37 38 24

Bomb (upper) (23) (25) Hatch



## **Colour Painting Guide**







Distributed by MINICRAFT MODELS, INC. 1510 W. 228th Street

Torrance, Calif. 90501

PACKAGED IN U.S.A.

